



EN

Thank you for choosing our bathtub. We hope you are fully satisfied with our product and usage of it!

**CAUTION!** Before starting the installation please read the installation manual.

The installation should be handled by qualified person. Defects that arise as a result of improper bathtub installation cannot be ground for a claim.

**Installation:** Freestanding bathtub is supplied in a cardboard box on a pallet, attached to it by four bolts. Before installation, remove all four nuts securing the bathtub to the pallet. Remove the bathtub from the cardboard and place it upside down on a secure cardboard covered surface. Unscrew the transportation bolts and replace them with four levelling feet, supplied with the bathtub. Attention! Decorative feet or integrated panel of the free-standing bathtub are not designed to withstand the weight of the product. Failure to install the levelling feet can result in damage to the product and may lead to an accident. Prior to installation, check the product is complete and free from possible defects or damage. Remove the protective film from the bathtub. Carefully check pipe connections for any leaks. Pour a small amount of water into the bathtub to check the flow of water through the drainage system and if necessary, adjust the setting of the bathtub using levelling feet.

If any questions, please e-mail [info@deko.ee](mailto:info@deko.ee)

EST

Täname, et otsite meie toote. Loodame, et meie vann pakub teile täieliku rahulolu!

**TÄHELEPANU!** Enne vanni paigaldust loe hoolikalt läbi see paigaldusjuhend.

Vanni peab paigaldama kogenud isik. Vanni valest paigaldusest tulenevad reklamatsioonid ei kuulu garantii alla.

**Paigaldamine:** Eraldiseisev vann tarnitakse papist pakendis, mis on asetatud puidust alusele ja on sinna kinnitatud transpordikruvidega. Eemalda pappkarbi kaan ja pane see põrandale. Pane vann tagurpidi pappkarbi kaanele ja eemalda transpordikruvid. Tähelepanu! Vanni dekoratiivsed jalad (lõvikäpad) või dekoratiivne esipaneel ei ole kujundatud vanni raskust kandma. Vann peab toetuma oma metalljalgadele ja dekoratiivsed jalad või esipaneel peavad jäädma pisut kõrgemale jalgadest. Enne paigaldust veendu, et toode on terve ja ei ole silmaga nähtavaid defekte. Eemalda vannilt kaitsekile. Kontrolli vanni ärvoolu võimaliketest veeleketest. Reguleeri vanni jalad, kasuta loodi.

Küsimuste korral saada kiri [info@deko.ee](mailto:info@deko.ee)

[www.deko.ee](http://www.deko.ee)